


4 x 1 STEREO AUDIO SWITCHING IN A CLASSROOM

Remote Source Selection and Volume Control



Description:

The classroom is equipped with three A/V sources (Computer, DVD and VCR) and an audio-only input on a wall plate. Staff selects the audio source and sets the level through the RDL RU-ASX4DR Remote Controlled Audio Selector using a D-RC4M Four Channel Remote Control and a D-RLC10M Remote Level Control. All video signals are run directly to the projector which provides video source selection. Sources may be muted by simply de-selecting the active input at the D-RC4M or by operating the MUTE switch on the D-RLC10M. The D-CIJ3D Consumer Input Jack Panel is used to balance the stereo signal of an MP3 player or any consumer source and to provide galvanic isolation.

Parts List	
Product	QTY
CP-3G	1
D-CIJ3D	1
D-RC4M	1
D-RLC10M	1
RU-ASX4DR	1

Recommended Pwr. Supplies	
Product	QTY
PS-24AS 24 Vdc 500 mA	1

Line Color Key	
—	Line Level Audio Signal
—	Loudspeaker Level
—	Control Signal
—	Video
—	Mic Level Audio Signal
—	Ground
—	Power
—	Miscellaneous