


HOUSE OF WORSHIP

Mixing Four Choir Microphones to Feed House Sound System



Description:

This is a simple four channel mixing system for choir microphones in a house of worship. The FP-MX4 Four Channel Audio Mixer mounts to any flat surface, typically above or near the choir loft. Each mic input has switch-selectable phantom power and an individual gain trimmer. The mixer can be set up and adjusted for different mic types or distances from the choir. The FP-MX4 output is available at both mic and line level, so it may be wired to either a mic or line input of the main house mixer. If choir monitors are installed, the FP-MX4 output is normally connected to feed only the main mix, not the monitors. This compact FP-MX4 provides simple, cost effective, studio-quality mic mixing.

Parts List	
Product	QTY
FP-MX4	1

Recommended Pwr. Supplies	
Product	QTY
PS-24AS 24 Vdc 500 mA	1

Line Color Key	
—	Line Level Audio Signal
—	Loudspeaker Level
—	Control Signal
—	Video
—	Mic Level Audio Signal
—	Ground
—	Power
—	Miscellaneous